

Helper Bar Assembly Instructions

These helper bars will fit any model we make.

Step 1: Remove cap (or mirror, accessory mounts etc.) from the top of the kingpin using a 5 mm Allen Wrench. If you have fenders or the chrome fender spacer, you can leave them on. Screw the included long M6 Bolt a few turns into the starnut, Using a hammer, hammer the bolt down until about $\frac{1}{4}$ " above the fender/spacer. Remove the bolt.



Step 2: Place the black piece into the kingpin. If it doesn't go all the way down put the bolt back in and hammer the starnut down a little more. Tighten the piece in using a 6 mm Allen Wrench.



Step 3: Place the 5 mm headset spacer on and then place the silver piece shown over the black piece and tighten using 6 mm Allen Wrench. The silver piece should face forward. Replace the cap (or accessory mount) on top.



Step 4: Place the vertical handlebar on the forward facing silver piece and tighten using a 5 mm Allen Wrench. The bend should tilt forwards. You can adjust how close these are to you by sliding them on the forward-facing silver pieces. Put a black handle on, push it down as far as it can go and tighten using the included 3mm and 4 mm Allen Wrenches. Place a rubber plug on top. Repeat all steps for the other side.



When finished it should look like this:

