

Canopy Neckrest Assembly- Important: Do not fully tighten anything until the very end



Step1: Open the velcro on the top. Put the 2 top poles in the pockets of the cover. Connect the top poles.



Step 2: Put PVC pipe into Silver Pieces, Place over Pillow shaft and tighten slightly.



Step 3: Put back pieces into top pieces and slide pillow assembly onto back pieces.



Step 4: Put larger side of brackets onto seat and put back supports into the smaller opening. Tighten slightly and check that both pieces are pushed into approximately the same depth.



Step 5: Put seat onto Trike. Tighten side brackets while at the same time rotating them to the back- they should be at approx. a 45 degree angle. Slide neckrest into desired position. You can also rotate the neckrest to bring pillow forward or back. Tighten everything fully. At this point you can also make sure everything is straight buy just adjusting the roof .